

Iron Maintenance

Keep it working like BRAND NEW

Over time, the water that you put in the iron can leave behind mineral deposits that, in turn, can clog the steam vents, resulting in your fabrics becoming stained with rust and mineral filled spots. Water from facets contain chemicals and minerals.

It is therefore important to always keep your iron clean; both the soleplate as well as the water tank.



SIMPLE STEPS TO TAKE

Empty water from water tank

You can prevent mineral build-up by only using purified or distilled water in the tank when steaming clothes.

If tap water is used, empty the water tank after each use whilst it is still hot. This allows it to dry completely. Never store an iron with water in the tank. A dirty water tank results in steam vents (the little holes in your sole plate) that are clogged with minerals from the water.

Cleaning the soleplate

Any scorch marks on the iron plate must be cleaned off as soon as possible. Starch spray, detergent, and fabric softener can build-up on the soleplate and an, in turn, stain fabrics.

Never wash or use an abrasive cleaner on the soleplate or with harsh chemicals that could scratch the plate because once the finish is marred, it is almost impossible to prevent staining or rusting.